

**Service Bulletin  
ERROR CODES**

**E-BAM  
11AUG2004**

---

When using the Terminal Utility Software, the E-BAM will show a report with the last column labeled "ALARM" and a number for the error. The manual does not give a description of this number. Below is a description of these numbers and their associated errors:

DESCRIPTION	#
No Errors	0
Tape Break	1
Beta Count Test Failed	2
Delta Pressure/Vacuum Failed	4
Pressure Test Failed	8
Flow Less than 5 LPM for greater than 2 minutes	16
Nozzle Failed up/down movement	32
Internal Communication Down	64
Low Battery	128
Delta T Alarm	256
Pump Over Temperature Alarm	512

Note that if there are combinations of errors, the number will be a multiple of the codes. For example, an E-BAM with a tape break and a nozzle failure would have a code of 33, which is a code 32 added with a code 1.

If you have any questions regarding this bulletin, please contact Mike Putnam in the Met One Service Department at one of the contacts below.

**Mike Putnam  
Service Supervisor**

[service@metone.com](mailto:service@metone.com)

**Ph. 541-471-7111 ext. 133  
Fax 542-471-7116**



**Met One Instruments, Inc.**

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116  
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)4124716  
Website: [www.metone.com](http://www.metone.com) Email: [service@metone.com](mailto:service@metone.com)

---