

Sensor Type Hand Helds

Date

Source Field Serv.

2/12/2003

Problem **Part Nr.** GT-521, GT-521, GT-COMM,

OK

Customer gets an error 75 Path / File Access Error when trying to download data from GT-521 or GT-531 Aerocet and using either GT-Comm or Aerocomm software.

Product AIR Products

Solution

This message will appear if the program was installed on a network or computer where the user does not have administrative rights. It is usually caused when the default data directory cannot be written to the hard drive because of lack of permission assigned by the network administrator. User will have to get the system administrator to allow access before data can be written to the directory.

