

When using Terminal Utility Software such as Windows HyperTerminal or the Met One Comet program, the E-SAMPLER will show a report with the last column labeled "ALARM" and a number for the error. Below is a description of these numbers and their associated errors:

<b>DESCRIPTION</b>	<b>#</b>
No Errors	0
Zero Cal Error	1
Not Used	2
Not Used	4
Pressure Error	8
Low Flow	16
Not Used	32
Internal Communication Down	64
Low Battery	128

**Note 1: Error Code #8 was added as of Firmware version 1.16. Firmware versions prior to this date do not have this code capability.**

**Note 2: If there are combinations of errors, the number will be a multiple of the codes. For example, an E-SAMPLER with a zero cal error and pump failure would have a code of 17, which is a code 16 added with a code 1.**

**If you have any questions regarding this bulletin, please contact the Met One Instruments, Inc. Service Department at 541-471-7111 or send an email to [service@metone.com](mailto:service@metone.com)**



**Met One Instruments, Inc.**

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116  
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)412-4716  
Website: [www.metone.com](http://www.metone.com) Email: [service@metone.com](mailto:service@metone.com)

---