

### **Issue**

The manual for the E-BAM has a procedure for periodic cleaning of the PMT. This procedure applies to units with serial numbers beginning with A or B and C series serial numbers manufactured prior to June 2003. The procedure is found in Rev. D of the manual section 3.3.2.2 step 6. All subsequent units must only be cleaned with low-pressure clean air.

### **Symptoms**

No Answer.

### **Solution**

All new E-BAMs (those manufactured after June 2003) have a new style of PMT installed. This tube cannot be cleaned with a Q-tip and alcohol like the older style of PMT. If the new style is cleaned with a Q-tip and alcohol the protective aluminum coating will be removed. The new style PMT should only be cleaned with low-pressure clean air. Care must be taken that the surface of the PMT not come into contact with any other surface.

### **Contact Information**

**Mike Putnam**

**541.471.7115 x 133**

**service@metone.com**



**Met One Instruments, Inc.**

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116  
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)4124716  
Website: [www.metone.com](http://www.metone.com) Email: [service@metone.com](mailto:service@metone.com)

---