

**Sensor Type** Hand Helds

**Date**

**Source** In-House

6/6/2001

**Problem**      **Part Nr.** KM-09, GT-321

**OK** X

Display is working but Pump will not run or unit will not count when pressing sample button.

**Product** AIR Products

### **Solution**

This is caused by one of two problems:

- (1) Battery low
- (2) Pump non functional

To determine which problem, select a particle size other than 0.3 micron. If the battery is too low, pressing the sample button will change the display back to the 0.3 micron selection.

If the problem is the pump, the unit will seem to be counting, but the pump will not be making a sound.

Solution:

If it is the battery, run unit until it goes dead and re-charge.

If it is the pump, send unit to factory to replace the pump. Pump is not a user serviceable part.

