

Sensor Type Hand Helds

Date

Source Field Serv.

8/13/2002

Problem **Part Nr.** GT-321

OK

GT-321 Will not sample unless switched off & on several times (even with freshly charged batt).

Product AIR Products

Solution

Found problem with clock circuit. Unit should be returned to factory for repair. Hand held particle counters should not be repaired in the field for the following two reasons:

- (1) Unit should be repaired at facility with availability of a clean room.
- (2) there is a potential danger of eye damage from the laser.

THERE ARE NO USER SERVICEABLE PARTS INSIDE.

