

E-SEQ-FRM Sequential Reference Method Sampler

The Met One Instruments, Inc. E-SEQ-FRM Is a US-EPA designated Reference Sampler FRM for PM_{2.5}, PM₁₀ and PM_{10-2.5} sampling methods.

The E-SEQ-FRM accommodates up to sixteen (16) 47-mm diameter filter samples and may be pre-programmed to a flexible, user-defined sampling schedule permitting more than 2 weeks of unattended daily operation.

The E-SEQ-FRM is modular in design, and may be easily disassembled and transported from one site to another. Its compact design and small footprint allows it to be moved in and out of locations with challenging ingress/egress. No disassembled component: system box, stand, or inlet assembly weighs more than 45 lb.

The E-SEQ-FRM offers an easy, intuitive event manager that permits programming of up to 16 independent sampling events.

Optional modem/communication package allows for remote access of stored data via RS232 interface. Data is also quickly and easily retrieved with a USB flash drive.



- Applications:**
- Regulatory criteria reference sampler networks: federal, state, local.
 - Academic studies
 - Comparative studies

Specifications

E-SEQ-FRM Sequential Reference Method Sampler

Method	Multi-event, sequential sampling of ambient air onto filter media
Regulatory Designations	US-EPA PM _{2.5} Reference Method (RFPS-0717-245) US-EPA-PM ₁₀ Reference Method (RFPS-0717-246) US-EPA PM _{10-2.5} FRM Reference Method (RFPS-0717-247) Korea Certification (APSC1-2016-01)
Filter Holders and Media	47 mm filter For US-EPA PM _{2.5} and PM _{10-2.5} sampling: Teflon 2µm pore size membrane filter (regulation required). For US-EPA PM ₁₀ reference sampling Pallflex TX-40 quartz filter and Teflon media.
Sample flow	Active flow control for 16.67 LPM. Sampled volume reported under actual and standard conditions
Calibration	Temperature, barometric pressure and multi-point flow.
Internal Data Storage	More than 130 days of interval data with 5 minute time resolution 132 filter records
Data Input/Output	Keypad/display for data retrieval and programming. RS232, USB serial and USB flash drive interface for data download
Operational Temperature	-30°C to +50°C
Power Requirements Physical	100-240 VAC 50/60 Hz 1.4 amps
Dimensions (inches) without PM ₁₀ inlet attached	System/Pump: 14.4 (w) x 14 (d) x 27 (h) Stand (at base) 24.5 (w) x 23.5 (d) x 29.6 (h) Total (at base) 23.5 (w) x 24.5 (d) x 56.6 (h)
Weight:	System/Pump 45 lb. Stand 10.5 lb, PM ₁₀ Inlet 5.3 lb

Specifications are subject to change at any time.



Met One Instruments, Inc.

1600 Washington Blvd. Grants Pass, Oregon 97526 **Phone:** 541.471.7111

Sales: sales@metone.com | **Service:** service@metone.com | **Website:** www.metone.com

August 2019