

**TWO SIMULTANEOUS PM
MEASUREMENTS IN ONE
MONITOR**
REAL TIME PM_{2.5} & PM₁₀



Introducing the newest addition to Met One Instruments, Inc. line of Ambient Indicative Monitors, the **ES-412 Portable Simultaneous Particulate Profiler**. As a Near-FEM (Federal Equivalent Method) product, the ES-412 provides the quality and day-to-day stability consistent with EPA quality objectives. This lightweight Particulate Profiler offers wireless, remote PM monitoring in a low profile, field deployable, weatherproof unit that measures both PM_{2.5} and PM₁₀ simultaneously.

Set up with ease for either temporary quick deployment or permanent installation, and have instant access to data on your smart phone, tablet, or computer. Data from the ES-412 is backed up internally and then transmitted to a nearby cell tower every 15 minutes. In the event of cell tower communication loss, the ES-412 will attempt communication continuously until it is regained. When this occurs, the ES-412 will transmit all missing data when communication is re-established, providing data security.

ES-412 PORTABLE SIMULTANEOUS PARTICULATE PROFILER



- RAPID DEPLOYMENT
- INTEGRATED GPS
- HANDLE DOUBLES AS MOUNTING BRACKET
- AUTOMATICALLY CONNECTS TO LOCAL CELLULAR PROVIDER



Transmitted data contains 15-minute averages for PM_{2.5} and PM₁₀ along with information on device power, flow, and internal diagnostics. Additionally, your custom web page dashboard offers a map showing where the unit is located with an internal GPS module. The ES-412 is a system that comes complete with cellular communications, a customized web page dashboard, a 3-year data plan, an AC power supply, and a transport case.

ES-412 PORTABLE SIMULTANEOUS PARTICULATE PROFILER

UP & OPERATIONAL WITHIN MINUTES

**1. EXTEND & SECURE
TRIPOD LEGS.**



**2. REMOVE ES-412 FROM TRAVEL
CASE & EXTEND FOLDING ANTENNA
FROM THE HANDLE. LOCK IN PLACE.**



**3. MOUNT THE ES-412 ON
TRIPOD. SECURE WITH
LOCKING BOLT.**



**4. PLUG POWER CORD
INTO RECEPTACLE IN THE
BASE. POWER ON.**



**5. ES-412 PROFILER WILL
BEGIN SAMPLING, WITH
THE FIRST DATA SET
TRANSMITTING TO YOUR
COMPUTER IN 15
MINUTES.**



ES-412 PORTABLE SIMULTANEOUS PARTICULATE PROFILER

FEATURES

- Remote Data – Locally Available on Personalized Web Page
- Easy, Unlimited Data Sharing
- Real Time Sensor Status
- Plug & Play – Internal Modem is Factory Configured & Activated
- Global Connectivity with 550+ Carriers
- Initial 3-Year Data Plan Included (est. Value \$500)
- Pre-Packaged in an IP64 Enclosure
- Free Data Collection and Analysis Software
- Power Supply & Cables Included
- Folding Antenna for Compact Storage
- Lightweight, Very Transportable.
- Rapid Deployment

EFFORTLESS DATA AT YOUR FINGERTIPS

TYPICAL DASHBOARD DATA PAGE



OPTIONAL ACCESSORIES

- Tripod
- Mobile Battery Power Supply
- Solar Charging Panel for Extended Operation.

CONTACT OUR SALES TEAM TODAY FOR A QUOTE:

SALES@METONE.COM

PARAMETER

Operation	Right angle light scatter detection using a laser diode as light source.
Measurement Resolution	0.1 µg/m ³
Number of Mass Channels	2 (PM _{2.5} , PM ₁₀)
Data Storage Intervals Sample	1, 5, 10, 15, 30, or 60 minutes
Air Flow Rate Sheath Air Flow	1.0 LPM
Rate	1.0 LPM
Flow Control Communications	Active volumetric flow control
Connections Operating	USB
Temperature Storage	0° to +50° C
Temperature Ambient	-20° to +60° C
Humidity Range	0 to 95%, non-condensing

Electrical

Power Supply	Universal 100-240 VAC input, 50/60Hz.
Power Consumption	12 VDC. Max operating current 1400mA.

Interface

Communication	Built-in CCS modem, Verizon™ 4G LTE (U.S. Domestic) GSM (Internationally with Over 550 Networks)
Communications Protocol	Terminal Command Set, MOI 7500 Protocol
Data Plan	3 years included

Physical

Weight	9.5 lbs. with power supply (4.31 kg)
Dimensions	5.125 in. Wide x 31 in. Height x 8.25 in. Depth (13cm x 79cm x 21cm)

SUPPLIED ACCESSORIES

- Operator's Manual
- Calibration Certificate (NIST)
- Power Supply
- Carrying Case
- Software Available from Website

Specifications are subject to change at any time.

