

AEROCET 532

PARTICLE MONITOR

FEATURES:

- LARGE FULL-COLOR
 LCD DISPLAY
- MENU-DRIVEN MULTI-FUNCTION ROTARY SCROLL WHEEL
- 10 USER-IDENTIFIABLE ALPHA NUMERIC LOCATION ID's
- INTEGRATED RH & TEMP SENSOR



SAMPLING MODES:

- COUNT & MASS
- SINGLE OR
 CONTINUOUS
- SELECTABLE TIME

Meet the newest addition to the Met One Instruments, Inc. lineup of handheld particle monitors: the Aerocet 532. This particle monitor has been optimized in functionality and ease of use with a 2.8" TFT full-color LCD display, making accurate measurement readings and operation more effortless than ever. Measuring both particle mass and particle count, this full-featured particle monitor is the perfect addition to any indoor air quality expert's tool kit.

The Aerocet 532 simultaneously measures and records PM₁, PM_{2.5}, PM₄, PM₇, PM₁₀, and total suspended particulate (TSP). Measurements are rapidly computed and totaled in as little as 60 seconds, recorded using an advanced profile algorithm. In addition to making mass measurements, the Aerocet 532 contains an 8-channel particle counter with a calibrated range of 0.3 to 10 microns.



AEROCET 532

PARTICLE MONITOR

An upgraded full-color LCD display makes measurement and selection effortless, supported by simple navigation. New features include an instrument wellness check, modifiable operating conditions, an internal toolbox, and last calibration date. The user may customize up to ten specific locations with alpha-numeric identification.

This rugged handheld device is constructed of an all-metal package coupled with an advanced user interface making it a first choice for professionals. The Aerocet 532 is designed for portable operation in difficult environments, with an internal battery life of 8 hours of continuous sampling.

Internal data storage allows for 15,000+ records of either mass measurements or particle counts, and complementary COMET software enables the user to easily download and analyze readings. Data outputs in a .CSV format.

TAILORED MASS CONVERSION

The particle counts from this device are converted to mass using a proprietary algorithm for typical-density aerosols. Accommodation for special particulate with different densities is provided through user-programmable K factors.

FLEXIBLE DATA INTERFACES

The stored data records may be viewed on the large, color display, or transferred to a computer via USB. Met One's included COMET software makes file transfers easy with the capability to import sample data into an excel spreadsheet. Utilize the ALL-NEW optional docking station



with WiFi, ethernet and RS-485 connectivity for even easier data transfer.

RH & TEMPERATURE SENSOR

Equipped with an integrated relative humidity and temperature sensor, data reports automatically include these parameters.

USER INTERFACE

Tactile navigation has been streamlined with a 'Start/Stop' button, a 'Menu/Escape' button, and a 'Press/Select' rotary knob for scrolling that doubles as a selection switch when pressed. The result is a faster, more intuitive interface.



AEROCET 532

PARTICLE MONITOR



Intuitive Navigation









Scrolling **Functionality Streamlines** Sampling

Integrated Tools Menu to Optimize **Device Capabilities**



Mass Mode

Mass Concentration PM₁, PM_{2.5}, PM₄, PM₇, PM₁₀, and TSP

Ranges Sensitivity 0.3µm

Concentration Limit 0 – 1,000 µg/m³

Sample Time 1, 2, 5, 10, 15, 30 or 60 minutes

Particle Count Mode

Concentration Limit 0 – 3,000,000 particles per cubic foot (105,900 particles/L)

Sample Time 1, 2, 5, 10, 15, 30 or 60 minutes
Size Accuracy Sensitivity ± 10% to calibration aerosol

Flow Rate 0.1 cfm (2.83 lpm)

Particle Size Ranges 0.3 μm, 0.5 μm, 1.0 μm, 2.5 μm, 4.0 μm, 5.0 μm, 7.0 μm and 10 μm

Electrical

Light Source Laser diode, 90 mW, 780 nm Battery Pack 7.4V Li-ion battery pack

AC Adapter/Charger Li-ion battery charger, 100-240 VAC, 50/60Hz

Communications USB-C Serial; With Optional Docking Station, RS-485, WiFi, & Ethernet

Battery Life 8 hours continuous operation

Interface

Display 2.8 inch TFT full-color LCD

Keyboard 2-button membrane keypad with rotary dial

Physical

Weight 1.0 lb, 13.5oz (0.84 kg)

Size Height = 8.8" (22.35 cm) Width = 3.75" (9.53 cm)

Thickness = 2.25" (5.72 cm) (without rubber boot)

Environmental

Operation Temperature 0° to +50°C

Relative Humidity < 95% (non-condensing)

Storage Temperature - 20° to +60°C

SUPPLIED ACCESSORIES

User Manual
 Zero Particulate Filter

Isokinetic Sample Inlet
 Calibration Certificate

• Carrying Case • RH & Temperature Probe

USB Cable
 Rubber Boot

- Comet Software
- AC Adapter/ Battery

Charger

OPTIONAL ACCESSORIES

 Swift 6.0 Flow Meter
 Docking Station w/ WiFi, Ethernet & RS-485 connectivity (p/n 83529)

Specifications are subject to change at any time.

